
Remote Motor Run / Interface Cable

922-040, 120 VAC XP-922-040, 220 VAC

Automatic gun applications



When the hot melt bath drops below the required level, the motor is activated to pump material into the bath.

Hot Melt Bath

When the bath has reached the appropriate level, the motor is turned off and the system stops filling.

OEM Supplied

Motor ON/OFF (Contact Closure)

冒

Example